

AR15 PIVOT PIN TOOL-PRO™

CLICK. SNAP. DONE. FASTEST WAY TO INSTALL A PIVOT PIN.

Highly engineered to turn a frustrating task into a quick and painless operation. The larger, all-metal construction provides extreme durability, precise fitment and is an ease to use with all AR15's.



INCLUDES PIVOT PIN
REMOVAL TOOL


EASILY INSTALL THE PIVOT PIN IN LESS THAN 60 SECONDS.




DETENT
PLUNGER

PATENT
PENDING


DURABLE METAL
CONSTRUCTION




STEP 1. Put the Pivot Pin Tool-Pro (PPT) fixture over the pin housing on the lower and insert large PPT pin.



STEP 2. Load spring first, then detent second into the PPT fixture. Compress the spring and detent with the PPT detent plunger and hold.



STEP 3. Rotate the PPT assembly 90 degrees and then remove the detent plunger.



STEP 4. Insert pivot pin as shown to drive out the pin. Finally, remove PPT fixture and snap pivot pin into closed position.

AR15

MASTER GRADE® BUILD TOOL

⚠ WARNING: This product can expose you to chemicals including Nickel (Metallic), which is known to the State of California to cause cancer. For more information, go to www.P65Warnings.ca.gov.



5480 NATHAN LANE NORTH, SUITE 120
MINNEAPOLIS, MN 55442 800.286.0567
info@realavid.com | RealAvid.com
© 2023 NEW REVO BRAND GROUP, LLC.

